Care and Cleaning

A few simple habits keep your TV lift cabinet looking good and working smoothly for years.



Natural Stacked Stone Sides

- Rinse with a garden hose and a soft brush
- Use mild soap for stubborn dirt
- Avoid acid cleaners and pressure washing up close



ArtisanPlank Sides

- Wash with mild soap, water and a soft brush
- Rinse and let it air dry
- No sanding, staining or sealing needed

Hammered Black Aluminum Top

- Wipe with a soft cloth, mild soap and water, then dry
- Skip abrasive pads, steel wool and harsh solvents
- Use coasters and trivets when you serve on it



Lift and Controls

- Keep the space above the cabinet clear before you raise the TV
- Lower the TV when you are done, and before storms or high wind
- Never spray water into the opening at the top
- Unplug the cabinet before you clean near the lift

Your TV

- Follow your TV maker's care steps for outdoor use
- Wipe the screen with a dry microfiber cloth
- An outdoor rated TV handles sun and humidity best



Seasonal Care

- Clean the sides and top at the start and end of each season
- Check the power cord and outlet for wear
- Check that the cabinet still sits level each spring
- In freezing weather, follow your TV maker's cold weather guidance

EASY CARE SCHEDULE

After each use
Lower the TV and wipe down the top

Every month
Wash the sides and dust the screen

Each season
Deep clean, check the cord and outlet, and check that the cabinet is level

Once a year
Run the lift all the way up and down. Call us if it sounds rough or stops

Good habits

- Keep the TV lowered when nobody is watching
- Keep remotes dry and change their batteries each season
- Give everything a full clean at the start and end of each season

Avoid

- Harsh chemicals, bleach and acid cleaners
- Pressure washing near the top opening or the outlet
- Setting heavy or hot items on the top while the TV is moving

Damage from improper care or maintenance is not covered by the warranty.